



OTI-BOT

DATA, CARE AND CLEANING GUIDE

Oti-Bot has been built and rigorously tested to work in your classroom alongside learners. However, there are some **care points** that should be considered to **help look after Oti**.

GENERAL CARE

- Lift Oti gently by the body and not the head.
- Do not shake or unnecessarily drop Oti.
- Where possible, store and charge Oti in an upright position and wearing a tummy.
- Store Oti in a cool location away from direct sunlight.
- Ensure that Oti is using the correct pen as per the user guide.
- Remember to remove the pen lid before inserting the pen.
- Do not insert the pen nib first.
- Do not manually move Oti's caterpillar tracks or head.
- Switch Oti off when not in use to preserve the battery life.
- Do not leave Oti on charge for prolonged periods of time.

CLEANING

- Clean Oti's body with a soft damp cloth, taking care not to allow excess moisture to enter any recesses.
- Use a clean dry cloth to clean underneath Oti's tummy.
- Clean Oti's camera visor with a dry cotton bud.
- Clean Oti's face visor with a soft dry cloth to avoid smears or scratches.

DATA AND SECURITY

- Oti connects to a tablet device by pairing the QR code displayed on Oti's face with the app. This ensures that the user is always in the same room as the robot.
- Oti does not connect to the internet.
- Oti stores all data to an internal hard drive which can be accessed via USB.
- Face data is stored locally and assigned to an animal character. To ensure data security, it is not permitted to store name data against faces.
- Oti will reset the connection between robot and tablet every hour and generate a new password. Tablet devices are therefore not able to save the connection details.